



MEGA8-P			
1	PC6(RESET)	23	D7
2	PC0(ADC0)	24	D6
3	GND	25	D5
4	PC1(ADC1)	26	D4
5	PC2(ADC2)	27	E
6	AREF	28	RS
7	AVCC		
8	PC3(ADC3)		
9	PC4(ADC4/SDA)		
10	PC5(ADC5/SCL)		
11	PB0(RXD)	2	RXD
12	PB7(XTAL2/TOSC2)	3	TXD
13	PB6(XTAL1/TOSC1)	4	TX_RX
14	GND	5	PK1
15	VCC	6	PK2
16		11	1WIRE1
17		12	1WIRE2
18		13	1WIRE3
19		14	S1
		15	S2
		16	S3
		17	MOSI
		18	MISO
		19	SCK